



## **Zero Penetration TPO Roof Solar Mounting Installation Instructions**


No professional drilling equipment or structural engineers are required; ordinary workers can perform standardized operations.

The rails and brackets feature a sliding self-aligning design, with a tolerance of  $\pm 5\text{mm}$ , improving installation efficiency by 70% compared to traditional solutions.

Every component has been fully optimized with better design, better support for easier faster installation experience.



**Foam Adhesive**



**1**

**CP-NBMO2-BR**



**2**

**CP-NBMO1-RL**



**3**

**CP-NBM01-FL-10°**




**4**

**CP-EC**





**5**


**SMC020**



**Fill in foam adhesive**



**Press the CP-NBMO2-BR**





**Slide the front and rear feet along the CP-NBMO2-BR, then tighten the bolts.**



**Place the photovoltaic panel.**

**Slide the CP-EP into the slot and tighten the bolts.**



**Install the next row of brackets using the connecting pieces.**



**East-west direction**



**Same direction**

**Complete the assembly of each type according to the steps outlined above.**